

BEFORE YOU BEGIN APPLICATION OF ANY TECDURA SELF ADHESIVE GEO-TEXTILES :

1. CHECK THE SURFACE IS SUITABLE FOR USE WITH TECDURA MATS

Suitable substrates include polished and decorative concrete, sealed marble, sealed terrazzo, porcelain & ceramic tiles, sealed granite, sealed timber, cured fibreglass, most primed metals and vinyl*

2. ALWAYS TEST TECDURA BEFORE USING

Apply to a small test area of approximately 300mm² to ensure the products suitability. If in any doubt please contact TecDura for more information. TecDura will not be held liable for failures due to incompatibility.

3. DO NOT USE HD OR MD STICKYMAT ON SURFACES THAT REQUIRE HIGH BREATHABILITY (MOISTURE RELEASE)

4. ENSURE THE SUBSTRATE IS FULLY CURED/DRIED OUT AS PER PRODUCT SPECIFICATION

5. CLEAR ALL DUST AND DEBRIS ON THE SUBSTRATE USING A VACUUM OR SOFT BROOM

Fig. 1 - Peel away approximately 12 inches of release paper from the Stickymat adhesive layer



Fig. 2 - Attach the adhesive side to the surface that needs to be protected



Fig. 3 - Working in pairs, roll out the mat progressively whilst peeling away the release paper. For large areas, use a dry roller to smooth out.



Fig. 4 - Ensure that each new length of mat overlaps on the white strip (shown in Fig. 4) to bond and seal the previous length.



Fig. 5 - Continue the process until the entire area has been covered.



Fig. 6 - Your surface is now covered by TecDura Stickymat



*Note: Application to combustible substrates will render LPS1207 certification void